



竹柄ミズ・金補ミズ 出来上り寸法


2R8寸




4R5寸




3R




5R




3R5寸



6R



4R



2R8寸~3R5寸まで ミズ房(小)
4R ~ " (大)

